

Siroflex

new

CARTRIDGE-CUT™

'A New Twist on Sealant'



STEP 1 SLIDE

'Slide' & 'click' the Cartridgecut into place.



STEP 2 ROTATE

Rotate once in the direction of the arrows and the cartridge will be cut open.



STEP 3 INSERT

To trim the nozzle insert into the guillotine to the required width.



STEP 4 TRIM

Press firmly and the nozzle will be accurately and cleanly trimmed.

CARTRIDGE-CUT™

Features and Benefits

- Opens 310ml cartridges in 1 rotation
- Fast accurate trimming of nozzle
- Unique design
- Safe and easy to use
- Robust construction
- Lightweight
- Neat – pocket size

Siroflex Limited, Dodworth Business Park, Barnsley, South Yorkshire, S75 3SP

Tel: 01226 771600 Fax: 01226 771601 www.siroflex.co.uk

International patent application no. PCT/GB2009/000374 Community design registration no. 1552555